

# Google Home

## Voice Activation User Guide

### **Available Commands**

#### **For what is currently playing**

“Hey Google, ask Channel Surfer what am I watching”

#### **Change to a channel number**

“Hey Google, ask Channel Surfer to tune to channel XXX”

#### **Search**

“Hey Google, ask Channel Surfer to find (TV program name)”

#### **Playback control**

“Hey Google, ask Channel Surfer to pause”

“Hey Google, ask Channel Surfer to resume”

“Hey Google, ask Channel Surfer to skip ahead 4 minutes”

“Hey Google, ask Channel Surfer to skip back 30 seconds”

#### **Watch previous channel**

“Hey Google, ask Channel Surfer to go to the last channel”

“Hey Google, ask Channel Surfer to go to the previous channel”

#### **Weather**

“Hey Google, ask Channel Surfer to show me the weather”

“Hey Google, ask Channel Surfer to show me the weather radar”

“Hey Google, ask Channel Surfer to show me the radar”

“Hey Google, ask Channel Surfer to show me the weather forecast”

“Hey Google, ask Channel Surfer to show me the forecast”

Use Voice  
Activation with  
Google Home to  
request a channel  
change, search for  
programming,  
and more.



100 S Main St., PO Box 515  
Woodward, IA 50276

(515) 438-2200

[www.minburncomm.com](http://www.minburncomm.com)



